SingSong Duet PRO
USER'S GUIDE

for Wii™

dreamGEAR®
www.dreamgear.net

PACKAGE CONTENTS:

- 2 High Quality SingSong USB Microphones
- 4 Microphone Head Covers in Assorted Colors
- User's Guide/Warranty Card
- Registration Card

SETTING UP THE MICROPHONES:

1. Make sure that the switch on the Microphone is turned to OFF.
2. Plug the Microphone's USB cable into one of the USB ports on the back of the Nintendo Wii.

Note: To sing a Duet in a game, plug both Microphones into both USB ports on the back of the Nintendo Wii.

3. Slide the switch on the Microphone to ON.
4. Load any Microphone compatible Wii karaoke game.
5. Start your singing career!

TROUBLESHOOTING:

Problem: The SingSong Duet Microphones do not function.

Solution:

1. Make sure the switch on the Microphone is turned ON.
2. Make sure the Microphones are plugged properly and securely into the USB ports on the back of the Nintendo Wii.
3. Make sure that the Nintendo Wii is powered ON.
4. Make sure there aren't any broken parts or anything else that would hinder any connection (i.e. the Microphone's USB plug to the Wii console or the Wii console's AC adapter to the power source).

Problem: The sound is unclear or muffled.

Solution: Make sure the Microphone head is clean and free of debris. DO NOT blow into the Microphone.